
SmitCare
14 Camberley Business Centre
Bracebridge
Camberley
GU15 3DP
01276 677888
www.smitcare.co.uk


Instructions for Fitting the Handle for the Aquarian Bath and Shower Boards

The handle for the Aquarian range of Bath and Shower Boards may offer enhanced mobility and security to user during sliding transfers and in use. The handle is designed exclusively for use with the SmitCare Aquarian range of boards.


1. Loosen the wingnut that secures the cleat and rotate it towards the middle of the board.



2. Loosen the blue wingnut and slide the bottom part of the handle assembly over the middle two slats of the board.



3. Position the handle about 10mm from the grey bracket and tighten the blue wingnut to secure in place.



4. Rotate the cleat back towards the outer edge of the board and proceed with fitting the board as instructed.

