



ASSEMBLY INSTRUCTIONS (2 PERSON OPERATION)

REMOVE THE LOCKING PINS AND INSERT THE CHROME POSTS INTO THE BASE TUBES, MAKING SURE THE IDENTIFIED END OF THE CHROME TUBE IS UPPER MOST, LOWER THE CHROME TUBE TO ITS LOWEST HOLE SETTING AND INSERT THE LOCKING PIN, REPEAT FOR ALL 4 TUBES.

POSITION THE BASES PARALLEL TO EACH OTHER, FAR ENOUGH APART TO TAKE THE HANDRAILS.

POSITION THE HANDRAIL ON TO THE CHROME TUBES, REPEAT FOR SECOND HANDRAILS.

WHEN THE PARALLEL BARS ARE IN POSITION AND SQUARE TIGHTEN UP THE 4 BOLTS USING A 13mm SPANNER (NOT PROVIDED).

