

Fitting instructions for Evacuation Overlay (EVO).

This Evacuation Overlay is designed to be permanently in place on top of a traditional Sprung mattress

- Remove all bedding, sheets and pillows from the bed.
- Lay the Evacuation Overlay (EVO) on top of existing mattress red side down, with foot pocket at foot end of bed.
- Release tucks/hook & loop straps down side of bed and tuck in under existing mattress.
- Make bed as usual.

In an emergency

- Locate foot pocket at foot end of bed and place patient's feet inside for security.
- Pull tucks from under sides of existing mattress.
- Wrap tucks tightly! over patient and secure with hook and loop fastenings.
- Locate pulling straps at both ends of bed.
- With one carer at the foot end and one at the head end pull to safety by strong looped pulling straps.

Fitting instructions for Evacuation Overlay (EVO).

This Evacuation Overlay is designed to be permanently in place on top of a traditional Sprung mattress

- Remove all bedding, sheets and pillows from the bed.
- Lay the Evacuation Overlay (EVO) on top of existing mattress red side down, with foot pocket at foot end of bed.
- Release tucks/hook & loop straps down side of bed and tuck in under existing mattress.
- Make bed as usual.

In an emergency

- Locate foot pocket at foot end of bed and place patient's feet inside for security.
- Pull tucks from under sides of existing mattress.
- Wrap tucks tightly! over patient and secure with hook and loop fastenings.
- Locate pulling straps at both ends of bed.
- With one carer at the foot end and one at the head end pull to safety by strong looped pulling strap