Functional & foldable

a Charles Buvers folding walking stick easily folds away and simply adjusts to the correct length.



To Adjust Height

Set to required height using push button and adjust length.

Tighten locking mechanism turning anti-clockwise.

To Fold

Pull sections apart from bottom to top in zig zag motion.

How to Hold Your Stick

Hold your stick with your index finger pointing down the length of the stick for maximum weight distribution.

Ideal Height

When the handle reaches the wrist bone it is at the recommended height

Weight Capacity

• 16 st •100 kg