




The **Chair Alertamat** is most effective when concealed under the chair cushion; activating the alarm when a user leaves their chair. This alerts the caregiver to ascertain the user's safety. The alarm is reset automatically when the user returns to the chair.

Both **Wired** and **Wireless** systems can be connected to a nurse call system for centralised activation, or used on their own, independent of a nurse call system to give localised alerts.

- > Hygienic, antibacterial easy-clean material
- > Dimensions: 25 x 38 cm (10 x 15")



## WIRED CHAIR ALERTAMAT

**CAM - Wired Chair Alertamat** - can be connected to a nurse call system with a 2 metre cable provided for centralised activation, or used on its own, independent of a nurse call system to give localised alerts through the Alerta Alarm Monitor (supplied as part of the system).

- > Plug-and-play system
- > System includes: 1x Chair Alertamat, 1x Alerta Alarm Monitor and 1x 2 metre cable

### Alerta Alarm Monitor

- > High, low and silent volume control
- > Multiple choice alarm tone
- > Adjustable delay to reduce false alarms
- > Low battery alert
- > Mains or battery powered
- > Takes 1x 9v battery




Battery operated



Mains operated



Alerta Alarm Monitor



## WIRELESS CHAIR ALERTAMAT

**W-CAM-T - Wireless Chair Alertamat** - comes with an Alerta Wireless Transmitter which connects to the Alerta Wall Point Receiver.

- > Wireless connect-and-play system
- > No cables, extra safe and versatile
- > System includes: 1x Chair Alertamat and 1x Alerta Wireless Transmitter (must be used with Alerta Wall Point Receiver - sold separately)

### Alerta Wireless Transmitter

- > Battery powered
- > Takes 2x 1.5v AAA batteries



### Alerta Wall Point Receiver

- > High, low and silent volume control
- > Low battery alert
- > Mains or battery powered
- > Takes 2x 1.5v AA batteries

