INSTRUCTIONS

CAUTIONS:

- 1- THE SUPER GRIP HANDLE IS TO BE USED AS A BALANCE ASSIST ONLY-DO NOT USE IT TO SUPPORT YOUR FULL BODY WEIGHT.
- 2- SINCE ANY SUCTION CUP BASED ITEM WILL LOSE STRENGTH OVER TIME, TO ENSURE MAXIMUM ADHESION YOU SHOULD RE-ATTACH THE SUPER GRIP HANDLE BEFORE EACH USE.
- 3- THE INDICATORS ARE DESIGNED TO ENSURE SUCCESSFUL INSTALLATION. THEY ARE NOT MEANT TO INDICATE PROPER ADHESION ON SUBSEQUENT USES. REATTACHING AND TESTING THE HANDLE REGULARLY IS THE ONLY WAY TO ENSURE THAT IT WILL ADHERE PROPERLY WHEN USED.
- 4. SOME SURFACES THAT APPEAR NON-POROUS MAY STILL HAVE MICROSCOPIC CRACKS THAT CAN CAUSE A SLOW LOSS OF SUCTION OVER TIME. THEREFORE IT IS IMPORTANT THAT THE ITEM IS TESTED BEFORE EACH USE.
- 5- IF YOU LEAVE THE SUPER GRIP ATTACHED FOR PROLONGED PERIODS WITHOUT REATTACHING IT THE ITEM MAY LOSE SUCTION. IN THESE CASES THE SUPER GRIP MAY NOT ADHERE TO THE WALL AS STRONGLY WHEN RE-APPLIED. LETTING THE SUPER GRIP REST ON ITS SIDE FOR 3-4 DAYS WILL ALLOW THE PVC SUCTION PAD TO RETURN TO ITS ORIGINAL FORM. YOU SHOULD THEN BE ABLE TO REATTACH IT WITH OPTIMUM SUCTION AGAIN. IN ANY CASE ALWAYS CHECK THE ITEM FOR FIRM SUCTION BEFORE EACH USE.



FOR MAXIMUM SUPPORT THIS ITEM MUST BE USED CORRECTLY. INCORRECT USAGE MAY CAUSE THE SUPER GRIP HANDLE TO LOOSEN AND NOT PROVIDE STABILITY.

HOW TO INSTALL:

.Place the Super Grip Handle where desired on bathtub rim or shower wall.

The suction cups must be over a completely smooth non-porous surface. Placing suction cups over cracks or grout lines between tiles will prevent them from holding properly and the item will be unstable.

To ensure correct readings the Indicators must face up or to the side. Never install the item with the Indicators facing toward the ground.


- 1. Clean mounting site of all dust, dirt and soap build-up. Be sure surface is completely clean and dry.
- 2. Flip up both latches so suction cups are released.
- 3. Push the handle firmly against the surface to squeeze out all excess air (Figure 1) and press the latches down firmly (Figure 3).
- 4. **IMPORTANT:** Check all INSTALLATION INDICATORS to make sure they are ALL displaying the **GREEN** color (Figure 4). If the **RED** color is showing, flip the latch up and reset. Do not place the indicator on a grout line as that may give you a false reading.
- 5. Retest the suction after a few minutes to make sure the item is adhering properly.


SPECIAL NOTE:


THE INDICATORS ARE AN ADDED FEATURE TO HELP YOU DETERMINE IF THE UNIT IS INSTALLED PROPERLY. YOU MUST STILL TEST THE GRIP MANUALLY BEFORE EACH USE TO ENSURE THAT IT HAS NOT LOOSENED SINCE THE LAST USE.


TO REMOVE:


- 1. Flip up both latches.
- 2. Pull back on the vinyl tabs to release the suction (figure 5). You may also slide the grip to the edge of the attached surface and lift off once the suction breaks. DO NOT PULL STRAIGHT UP AS THIS CAN CAUSE UNDERCARRIAGE DAMAGE.











JOBAR INTERNATIONAL (3/12)

MADE IN CHINA

C:\Users\saffellk\AppData\Local\Microsoft\Windows\Temporary Internet Files\OLK79E1\ZB5330 Super Grip Handle instruction - NOTREH.doc