

## #662 Two Way Hands Free Magnifier with Light

### Fitting the neck cord

1. With the light button facing you open the two-way handle.
2. Side open the compartment door, which is located in the left half of the handle. The neck cord is stored inside.
3. Snap the two plastic clips at each end of the cord in position on both edges of the lens.
4. Adjust the cord length for comfort.

### Magnification

1. Main lens x 1.5
2. Small area x 4

### Battery Installation and light operation

1. With the light button facing you open the two-way handle.
2. Side open the battery compartment door, which is located in the right half of the handle.
3. Insert 2x AAA batteries. Observe polarity (+ =) to avoid leakage.
4. Replace battery door making sure it is properly closed.
5. The side switch under the lens operates the light. Please ensure this is turned off after use to save battery life.

### Battery Information

1. Use only designated battery type. Do not mix battery type. Do not use rechargeable batteries.
2. Read instruction carefully and install batteries correctly observing the polarity (+ =) sign to avoid leakage.
3. Do not attempt to recharge non-rechargeable batteries.
4. Do not use mercury oxide batteries.
5. Always replace sets of batteries at the same time. Do not mix new and old batteries.
6. Do not short out battery contacts.
7. Remove exhausted batteries to avoid leakage.
8. Remove batteries from product when not intended to use product for an extended period of time.
9. Do not dispose of batteries in fire.
10. Do not immerse electric operated product. Wipe clean only.

Please retain this information for future reference.



Lifemax Ltd  
The Business Centre  
Brimpton  
Reading RG7 4TN  
[www.lifemaxuk.co.uk](http://www.lifemaxuk.co.uk)

