

USER INSTRUCTIONS COMPACT EASY PLUS ROLLATOR

Silver S23447 S50608 Red



🗥 General Safety Warning 🗥

Please make sure that you read and follow these instructions carefully. Keep these instructions in a safe place for future reference.

1. INTENDED USE

The Compact Easy Plus Rollator gives support and assistance to those unable to, or who lack the confidence to, walk without some level of support. This Rollator is for indoor and outdoor use.



2. KEY DIMENSIONS

Minimum Handle Height: 805 mm Maximum Handle Height: 935 mm

Width: 220 mm (folded) - 650 mm (Unfolded).

Maximum User Weight



3. SAFETY



Before use, make sure that:

- The rollator is locked in the open position.
- · The handles are at the same height.



Only:

- Use as a walking aid in the forward direction.
- · Use the specified accessories and spare parts for this rollator.
- · Transport loads using the bag supplied (maximum load 5 kg).



DO NOT:

- Exceed the maximum user weight.
- · Adjust the rollator while in use.
- · Use the rollator on stairs or escalators and take care on steep hills.
- · Sit on the seat without locking the brakes first.
- Use the seat to transport people or objects.
- Use the seat without the backrest in place.
- Hang items from the handles as this will affect the stability of the rollator.

4. UNPACKING

Remove the packaging and check all parts carefully. Contact your supplier immediately if parts are missing or damaged and do not try and assemble.



Contents:


- 1. Compact Easy Rollator.
- 2. Bag.
- 3. Bag Strap.
- 4. Back Rest.

5. ASSEMBLY

5.1 Unfolding the Rollator



1. Squeeze the handle clips together to release the handles from the frame.







2. Lift the handles to an upright position making sure the handle bracket collar fits securely over the locking bracket.



3. Pull the locking lever towards you, rotating through 180 degrees, to lock the locking bracket washer against the handle bracket collar.



- 4. Rotate the locking lever 90 degrees, making sure the lever locks into place as shown.
- 5. Repeat for the opposite side.



6. Undo the seat frame clip.



7. Push down on the seat tubes until they click into place.

Note: Keep fingers from under the seat tube. The Rollator is now fully open.

5.2 Fitting the Backrest



1. Slide the backrest onto the handle bracket.



- 2. Use a cross-head screwdriver to fasten the backrest bracket to the handle bracket.
- 3. Repeat for the opposite side.

5.3 Removing the backrest

Reverse the fitting process in Section 5.2.

5.4 Fitting the Bag



Push the bag fixing tabs onto their sockets in the seat tubes, making sure the tabs click into position.

Note: Make sure the bag is fully secure before use.

5.5 Removing the Bag

Reverse the fitting process in Section 5.4.

5.6 **Handle Height Adjustment**

Adjust the Rollator handle height so that when the user's arm is down to their side, the hand-grip is at wrist height. This will ensure the arms are at an approximate 20°-30° bend when using the Rollator.



- Push and hold the handle button-clip, then raise or lower the handle until the button-clip clicks into the position you need.
- Repeat for the opposite handle. 2.



Warning: Make sure that the handles are at the same height. Make sure the button-clips are fully engaged.

6. USING THE ROLLATOR

Brake Operation



- To slow down or stop the rollator, pull both brake handles up.
- 2. To apply the parking brake, push the brake handles down until they lock into place.



Warning: Apply both brake handles.

Pull both handles up to release the parking 3. brakes.



Warning: If the brakes fail to stop or lock the wheels, stop using the rollator immediately. Do not use the rollator again until the brakes have been checked and correctly adjusted. Refer to Section 6.2.

6.2 Brake Adjustment



Warning: This section requires some technical ability. Do not attempt to carry out the adjustment unless you are confident to do so. Incorrectly adjusted brakes can lead to injury, please contact your supplier if you require assistance.



Tighten the Brakes

While holding part (A), use a 10 mm spanner to tighten the locking nut (B) in a clockwise direction.

Note: You may need to use a pair of pliers to hold part (A) still during the adjustment.

Loosen the Brakes

While holding part (A), use a 10 mm spanner to loosen the locking nut (B) in an anti-clockwise direction.

Note: You may need to use a pair of pliers to hold part (A) still during the adjustment.

Note: There must be a gap of 2-3 mm between the brake mechanism and the wheel, when the brake lever is released.

Test the brakes in accordance with Section 6.1.

6.3 Folding the Rollator

Note: Remove all items from the bag before folding.



- 1. Lift the seat handle until the seat tubes release from the brackets.
- 2. Reverse the unfolding process (refer to Section 5.1).

6.4 Using the Walking Stick Holder



Place the walking stick in the cup, then clip into place.

7. MAINTENANCE

Check all button clips are fully clicked into position. Check all wheels can rotate freely.

Regularly check for wear and damage. Immediately report any suspected faults or damage to your supplier and take the product out of use.

Check brakes before each use. See Section 6.1.

8. CLEANING

Make sure that all dirt and debris is removed from around the wheels, axle and brakes.

To clean the bag wipe with a damp cloth. Do not machine wash.

Clean the frame regularly, using a general purpose, neutral detergent and warm water.

Please check the suitability of the cleaning products before use. Do not use abrasive cleaners or cloths as these could permanently damage the surface and invalidate any warranty.

Always allow the product to dry thoroughly prior to use or storage.

9. ACCESSORIES & SPARE PARTS

S39119 Compact Easy Plus Bag Spare

For more details please visit our website:

www.nrshealthcare.co.uk or call Customer Services.

10. PRODUCT DISPOSAL

Thoroughly clean this product before disposal.

This product is manufactured from metal and plastic and can be disposed of through Local Authority Household Waste and Recycling Centres or through Local Trade Waste Collectors.

11. PRODUCT GUARANTEE

NRS Healthcare guarantee this product for a period of 24 months, from the date of purchase, against faulty materials and workmanship.

This guarantee does not cover abuse, interference or tampering with any part of the products. Issues arising from fair wear & tear and customer misuse are not covered.

This guarantee covers domestic use only. If the product is used in commercial or semi-commercial settings such as care homes, schools, rental or communal accommodation etc, the guarantee is valid for one year only. Consumable parts are also guaranteed for one year only.

Any guarantee issued by NRS Healthcare does not affect your statutory rights.

12. GLOSSARY

	Manufacturer	LOT	Batch Reference Code	(i	Consult the instructions for use
	Warning	EC REP	Authorised representative in the European Community	MD	Medical Device
REF	Item/Catalogue number	CE	European Conformity / Conformité Européene	U K Q	UK conformity assessed marking
21st 135kg	Maximum User Weight				





Tel: Customer Services: +44 (0)345 121 8111

Email: customerservice@nrshealthcare.co.uk

NRS Healthcare is a leading supplier of community equipment and daily living aids.

Please visit one of our websites to view our full range of products:

www.healthcarepro.co.uk or www.completecareshop.co.uk