

Bewl Shower Commode Chair



CE VB502 Assembly and Operating Instructions

This file is available to view and download as a PDF at www.aidapt.co.uk. Sight impaired customers can use a free PDF Reader (such as adobe.com/reader) to zoom in and increase the text size for improved readability.

N.B. This equipment must be installed by a competent person and a risk assessment undertaken as to the suitability of the chair for the particular user.

127kg (20 st) weight limit

Do not exceed the weight limit stated as doing so could put the user at risk

ASSEMBLY

The chair is provided to you packed in cube form. Please examine all components for any visible damage before use. If you see any damage or suspect a fault, please contact your supplier immediately.

In this case, please do not use your product as it may compromise the safety of the user.

NB. When transferring sideways from the chair, a risk assessment may be needed as to the suitability of the chair for the particular user.

NB. Arm rests are for comfort only.

NB. Indoor use only.

NB. When pushing the chair, attendants must not 'ride' (i.e. put all their weight) on the pram handle.

The package contains the following components:

- The main frame with four braked castors attached
- Detachable grey horseshoe aperture seat (attached to the main frame)
- Grey horseshoe seat infill
- Detachable back
- Detachable footrests

PLEASE READ THESE FOLLOWING INSTALLATION INSTRUCTIONS CAREFULLY.

- 1. Remove all contents from the box
- 2. Remove the white cardboard packing tubes taped around the frame (this is to prevent damage during transit and not part of the chair)
- 3. Place the assembled base on a level floor
- 4. At the rear of the chair (or removable back) you will see two black threaded wheel nuts; undo the wheel nuts and remove from the frame
- 5. Place the two legs of the back into the locating holes at the rear of the chair frame
- 6. Re-insert the black nuts through the frame and back and secure by turning the black lock nuts until you feel the nut biting against the leg of the back
- 7. Do not over tighten
- 8. Do not use tools as it is only necessary to have the back secured finger tight

FOOTRESTS

Your footrests may be packed separately to the main chair. Please examine your footrests for any visible damage before use. If you see any damage or suspect a fault, please contact your supplier immediately. In this case, please do not use your product as it may compromise your safety.

- 1. Remove the footrests from their packaging.
- 2. You will see on each of the front legs of the main frame about 150 mm high from the castor 2 retaining lugs either side.
- 3. Take the footrests and align the holes in the inverted 'U' section with the lugs and lower down into place.
- 4. Rotate the footrests towards the commode so that they clip into place.

BRAKED CASTORS


Do not attempt to push the Bewl shower chair with the brakes applied, this will damage the brake mechanism and may compromise the safety of the user.

NB. Please regularly check the castors and the brakes for proper operation and that the castors are securely fitted to the chair legs.

CASTOR REPLACEMENT

NB: We would recommend castor replacement is done by Aidapt or a qualified technician

- Remove the existing castors using a short reach 8 mm Allen key (available from Aidapt).
- Replacement M12x35 bolts are provided with each castor, the removed bolts should be disposed of.
- 3. Apply a thread locking fluid to the bolt to lock the assembly securely. We recommend the use of Bondloc B243 or Locktite 243.
- Assembly should be screwed tightly and the castor should sit flush with the frame. (i.e. there should be no gap between the castor and the frame)



NB: Where leg extension pins are in place it is recommended that the extension pins are replaced at the same time as the castor.

For further technical details contact Aidapt.

APERTURE COVER

When transferring to and from the Bewl Shower Chair, be careful not to apply weight to the grey removable toileting aperture cover. This may cause the padded aperture cover to push through. **NB. The padded aperture cover is not designed to be load bearing.**


COMMODE BUCKET

To remove the commode bucket, simply slide the bucket out from the chrome runners at the rear of the commode. Cover the top of the bucket to avoid splashing, carefully dispose of the contents into a proper sluice or WC. Never use an open drain, sink or basin. This could cause a serious health risk. To avoid the possibility of trapping, do not slide the commode pan on or off the rails while somebody is sitting on the chair.

Clean out the residue with a suitable disinfectant and refit to the commode after use **NB. Always remove the commode bucket prior to removing the grey horseshoe seat.**

SEAT

The Bewl comes with a detachable grey horseshoe seat (see Fig. 1) as standard. A pear shaped aperture seat is also available (see Fig. 2) and may be required by the user, based on the risk assessment.



APERTURE COVER

When transferring to and from the Bewl Shower Chair be careful not to apply weight to the grey removable toileting aperture cover. This may cause the padded aperture cover to push through.



NB. The padded aperture cover is not designed to be load bearing. **CLEANING**

A useful guide to decontamination is MHRA leaflet DB2003(06).

Do not use abrasive cleaners as this could damage the surface of the equipment. For cleaning, wipe with a clean cloth soaked in detergent solution and wring out. Depending on the detergent manufacturer's instructions the solution may be heated.

Wipe all surfaces of the equipment and the cloth should be re-immersed periodically and the detergent changed frequently. The detergent should be rinsed or wiped off using a clean cloth immersed in clean water and wrung out.

To disinfect make sure the equipment has been cleaned and dried and then wipe over with a clean cloth and a compatible liquid disinfectant. After disinfecting clean with clean water and dry. When using detergent or disinfectants then please refer to manufacturers' instructions and if unsure then consult your local Infection Control Specialist for advice.

This product is not suitable for cleaning with moist heat or autoclaving.

REISSUE

If you reissue or are about to reissue this product, please thoroughly check all components for their safety, also check all upholstery for security, splits, etc. If in any doubt, please do not issue or use, but immediately contact your supplier for service support.

When reissuing, a risk assessment may be required as to the suitability of the chair for a particular user.

MAINTENANCE

Please make a safety check of the product at regular intervals or if you have any concerns, paying particular attention to the castors.

Aidapt Bathrooms Ltd, Lancots Lane, Sutton Oak, St Helens, WA9 3EX Telephone: +44 (0) 1744 745 020 | Fax: +44 (0) 1744 745 001 | Web: www.aidapt.co.uk

Email: accounts@aidapt.co.uk | adaptations@aidapt.co.uk | sales@aidapt.co.uk