KIT 4 75 cm x 25 cm x 0,2/15,8 cm

1 x   **1** x   **1** x

3 x   **3** x   **6** x   **3** x   **3** x   **12** x   **9** x   **24** x   **1** x

| 12527 | 12695 | | 12690 | 12550 | 12500 | 12732 | 12742 | Security |

Before assembly. Read the
Saftey instructions carefully.

WHEN THE RAMP IS TOO HIGH

①

3 x

②

③

④

5

6

7

8

WHEN THE RAMP IS TOO LOW

1

2

3

4

3 x

5

6

FIXING THE RAMP
(Screw fasteners required)

RAW WOODEN FLOOR   CARPET   CONCRETE

1   x **3**

2   x **3**

3   x **3**

4

5   30 sec.   30 sec.

6

7   x **3**

FIXING THE RAMP
(Screw fasteners unsuitable)

LACQUERED WOODEN FLOOR   CERAMIC TILES   LINOLEUM

① x **3**

② x **3**

③ x **3**

④

⑤

⑥ 30 sec.   30 sec.

⑦

FIXING THE RAMP
(Screw fasteners unsuitable)

POLISHED / WAXED: WOODEN FLOOR   CERAMIC TILES   LINOLEUM

1

x **3**

2

3

4

FIXING A RAMP OUTDOOR

①

②

③

④

⑤

⑥

Repeat the procedure for all 3 Expansion Guides