

Bright LED Motion sensor light - TDL002

This light provides a bright (50-80 lumens) white light when it senses movement up to 3 metres away. It will only come on in low light conditions to avoid battery wastage. It switches off 30 seconds after movement stops.

It is ideal to light dark cupboards, wardrobes and draws, or for additional low level lighting on dark stairs or passages etc.

The light swivels in its frame to angle the light to the required area.

Powered by 3x AA 1.5V alkaline batteries (not supplied)

It can be fixed on any flat dry indoor or weather protected surface using screws or the double sided sticky pad provided.

Orientation

The light is approx. 259x26x22mm (10.1x1.1x0.8 inch) It is a tubular shaped plastic lamp rotating in a flat metal frame. On the **Front** of the lamp at one end is a square black button switch and a round dome shaped opaque movement sensor.

On the Back of the lamp in the centre is a battery compartment with a small semi circular catch at one end.

Operation

To insert or change **Batteries**, turn the lamp tube whilst keeping the frame still so that the back of the lamp is facing you, locate the battery cover catch and lightly pull it towards the centre whilst lifting to remove the cover. The 3 "AA" batteries slot inside the tube one after the other with the positive terminal first, the final battery should be first pushed lightly against the spring (negative end) in the opposite direction and then lowered into place against the other two batteries. The cover can then be replaced.

To switch lamp on or off:

Press the black square button on the front of the light, when the light comes on the movement sensor is activated, the lamp will switch off after 30 seconds and is now in automatic switching mode, it will light again when movement is detected. (The sensor only works in dusk or dark light levels). The lamp can be switched off at any time by pressing the black button again, this will also switch the sensor off.

Guarantee

This product is guaranteed from manufacturing faults for 12 months from date of purchase. If you have any problems with the product, firstly contact your retailer or supplier.

At the end of the products life you can return it to the supplier or manufacturer for free of charge disposal. This is to comply with Waste electrical and Electronic Equipment Directive.