

SUPERSIZED COMFORT TOILET SEAT

CAUTION:

- **IF YOU HAVE ANY DOUBTS ABOUT THE INSTALLATION SEEK THE SERVICES OF A QUALIFIED INSTALLER.**
- **DO NOT OVER TIGHTEN THE SCREWS.**

REMOVING YOUR OLD TOILET SEAT:

- Pry open the bolt caps. (Some toilet seats may not have the bolts caps and the bolts are exposed)
- Use an adjustable wrench to hold the nut located on the underside of the seat bolt as you unscrew the bolt from the top. Once both bolts are removed, remove the old toilet seat.

INSTALLATION INSTRUCTIONS:

- Unsnap the bolt caps and align the holes of the seat with the holes on the toilet base.
- Place a washer on each bolt and insert them through both holes as shown on the illustration below (left).
- Thread both nuts onto each bolt from the underside as shown on the illustration below (right) until they are hand tight.
- Center the toilet seat and tighten the nuts using the adjustable wrench. Do not over tighten, slightly beyond snug tight is good enough.
- Replace bolt caps.

