

UNI-COM

Premium vibrating portable door chime

Model: 67313

Operating instructions

Please read **all** of the operating instructions carefully before use and keep in a safe place for future reference.

Quick set up guide

Remove the battery tab from the bell push by gently pulling it in the direction of the arrow.

Slide the switch on the side of the chime unit to select your operating mode:

- Vibrating + flashing + chime sound
- Vibrating + flashing
- Chime sound only

Slide down and remove the battery cover on the back of the chime unit. Insert 2 x AA batteries, observing the polarity markings. You will hear a double "beep".

Within 30 seconds of the double "beep" press the button on the front of the bell push. The chime will operate as per the mode you have selected.

Note;

The bell push button will light green to confirm it is transmitting.

Battery replacement - bell push

Remember to replace the battery in the bell push every 12 months.

Insert a flathead screwdriver into the slot on the bottom of the bell push. Gently push and twist to separate.

Insert a flathead screwdriver into the slot below the battery and gently prise to remove. Insert 1 x CR2032 button cell battery, ensuring it is positive (+) side up.

Repeat the quick set up guide;

After inserting the new batteries - press the button on the front of the bell push within 30 seconds of the double "beep" to reconnect.

Sound selection

The vision door chime has 8 selectable sounds.

Insert a flathead screwdriver into the slot on the bottom of the bell push. Gently push and twist to separate.

Press the black buton marked "S" inside the bell push. Each time you press the button it will play a different chime sound. Stop when you hear the one you want.

Refit the two sections of the bell push back together ensuring the rubber seal surround has not moved and is still correctly positioned.

Battery replacement - chime unit

Repeat the quick set up guide;

After inserting the new batteries - press the button on the front of the bell push within 30 seconds of the double "beep" to reconnect.

Installation

Test the units in their intended locations before you fix them in place.

The operating range will be reduced if the bell push is mounted on metal or double glazed uPVC door frames. Electrical / wi-fi equipment and the thickness or number of walls between the bell push and the chime unit will also reduce the operating range.

The bell push must be mounted the correct way up (as per the arrow inside the back plate).

The portable chime unit can be used wall mounted, free-standing or carried around the home and garden.

Bell push - adhesive pad

Ensure the surface is clean and flat before applying.

Bell push - screws

Separate the bell push and punch out the holes on the back plate. Attach to the wall using the wall plugs and screws supplied.

Chime unit - wall mounted

Fit the screw to the wall using the wall plug. Insert the screwhead into the keyhole on the back of the chime unit and slide down.

This is required if you want to add another bell push to your door chime set up. Instructions on how to do this can be found within the troubleshooting guide overleaf.

UNI-COM

Premium vibrating portable door chime

Model: 67313

Troubleshooting guide

Please do not hesitate to contact our friendly customer service team who will be more than happy to help you with any problems you are experiencing with your door chime set up

My door chime is not working?

Does the green LED illuminate on the bell push when you press the button?

If NO:

• Check to see if the battery tab has been removed. It should be sticking out the side of the bell push and can be removed by gently pulling in the direction of the arrow.

• Replace the battery in the bell push. Please refer to the **Battery replacement – bell push** section in the operating instructions.

If YES:

• Replace the batteries in the portable chime unit. Please refer to the **Battery replacement – chime unit** section in the operating instructions. Do not use high powered Li-ion, professional alkaline or rechargeable batteries.

• The chime unit may not be receiving a signal from the bell push, this can be caused by internal walls or uPVC frames. Move the chime unit closer to the bell push.

• The chime unit could be receiving interference from other electrical and wireless devices. Please refer to **My chime unit sounds when nobody is pressing the bell push?** section within this troubleshooting guide to set your door chime up on a different channel.

My chime sounds when nobody is pressing the bell push?

The common cause for this is that your chime unit is picking up outside interference from other wireless transmitters. Do not worry, all Uni-Com door chimes are programmed with 256 randomly selected channels to help avoid such a problem.

(1) Remove the battery from the bell push.

(2) Remove the batteries from the portable chime unit.

(3) Leave the units for a minimum of 10 minutes.

(4) Re-insert the batteries in the chime unit. You will hear a double “beep”.

(5) Within 30 seconds re-insert the battery into the bell push and press the button on the front. The chime unit will sound.

Your door chime will now be set up on a different channel.

As stated above the channels are randomly selected so you may need to repeat the above process more than once.

My door chime only works temporarily (I keep having to reconnect the bell push to the chime unit)?

The common cause for this is that the power in the bell push battery is getting low (meaning that your door chime set up keeps losing signal and why you repeatedly keep having to pair the bell push to the chime unit).

Firstly perform a factory reset on your door chime set up;

(1) Press and hold the CODE button on the side of the portable chime unit, while continuing to hold the CODE button remove and then reinsert the batteries.

Then;

(2) Replace the battery in the bell push. Please refer to the **Battery replacement – bell push** section in the operating instructions.

A different chime sounds every time the bell push is pressed?

(1) Remove the front of the bell push by gently inserting a flathead screwdriver into the slot on the bottom, gently push and twist to separate.

(2) At the same time press and hold for 5 seconds the chime selector button marked “S” (inside the bell push) and the button on the front of the bell push.

(3) Before refitting the front of the bell push remember to use the chime selector button marked “S” to choose the chime sound your want.

How do I add another chime unit to my existing door chime set up?

All Uni-Com door chimes work together and you can add unlimited chime units to your set up. This will increase the sound area and means you can have a Uni-Com chime unit in every room in your house if you wish.

(1) If you have a new portable chime unit insert the batteries, if you have a new plug-in chime unit plug-in into the mains socket and switch on. You will hear a double “beep”.

(2) Within 30 seconds of the double “beep” press the button on the front of your existing bell push. **Both** your new and existing chime units will sound.

How do I add another bell push to my existing door chime set up?

A Uni-Com bell push will work with all current Uni-Com models of door chimes. Please note however that other manufacturers bell pushes will not work with Uni-Com door chimes.

A maximum of 4 bell pushes can be paired to the same chime unit.

(1) Remove the battery tab from the new bell push by gently pulling in the direction of the arrow.

(2) Press and hold the CODE button on the side of the portable chime unit until you hear a “beep”.

(3) Within 5 seconds of the “beep” press the button on the front of the new bell push. The chime unit will sound.

Each bell push can be programmed with a different chime sound. Please refer to the **Sound selection** section in the operating instructions.

Specification


Frequency: 433.92MHz
R2 device

Hereby, Uni-Com (Global) Ltd declares that the radio equipment type door chime is in compliance with the Radio Equipment Regulations 2017 (SI 2017/1206). The full text of the UKCA Declaration of Conformity is available to view at www.uni-com.co.uk.

Safety warning

For indoor use only (operating temp: 0°C to 40°C). Do not drop either unit or subject to excessive blows. The bell push is weather resistant, do not submerge. Do not mix new and used batteries. Do not mix different types of batteries. Exhausted batteries must be removed immediately. Failure to follow these instructions could result in fire, electric shock, injury or damage to persons, product or property and will invalidate the guarantee.

Batteries

The bell push uses 1 x CR2032 button cell battery and the chime unit uses 2 x AA batteries. They should be removed prior to disposal. Help the environment by disposing of your products and batteries responsibly.

Guarantee

This product is guaranteed for one year from the date of purchase against faulty parts or workmanship. It does not cover batteries or physical damage to the units. Proof of purchase required. This does not affect your statutory rights.

Keep out of reach of children

WARNING:
Button cell batteries are a choking hazard. Swallowing can lead to chemical burns, perforation of soft tissue and death. If consumed seek immediate medical attention.

Uni-Com (Global) Ltd.
1 & 2 Enterprise Way,
Edenbridge, Kent, TN8 6EW

+44 (0)1732 865238
info@uni-com.co.uk
www.uni-com.co.uk