

Making Adjustments: Press the MENU button to display the on screen menu: Please Note: Changes can only be made to the line when highlighted in brackets and underlined. Use the UP or DOWN button to highlight the line to apply changes. Use the LEFT or RIGHT buttons to underline the text for adjustment. When underlined, use the UP or DOWN button to make changes required.

Set Time	07:10AM
Set Date	17-12-2010
Time Mode	12 Hours
Date Mode	Day-Mounth-Year
Language	English
Morning Time Set	08
Afternoon Time Set	12
Evening Time Set	17
Night Time Set	23

Line 1, - Set Time:

Press **LEFT** or RIGHT buttons to underline the hour <<u>07</u> : 10 > change the hour by using UP or DOWN buttons. Then press the LEFT or RIGHT buttons to highlight the minutes < 07 : 10 >Using the UP or DOWN buttons to adjust (Press Menu to close)

Line 2. - Set Date: Select preferred Date Mode on Line 4 before adjustments. Press buttons LEFT or RIGHT to highlight the Day: <17 - 12 - 2010 > or <12 - 17 - 2010> use UP or DOWN button to adjust. Changing Month / Year when underlined. (Press MENU to close).

Line 3, - Time Mode: 12 hr or 24 hr

Select the preferred mode by using the LEFT or RIGHT buttons. (Press MENU to close)

- Line 4, Date Mode: < Day Month Year > or < Month Day- Year > Select preferred Mode pressing LEFT or RIGHT buttons. (Press MENU to close)
- Line 5, Language: Select preferred language to display by using LEFT or RIGHT buttons. (Press MENU to close)

The following setting is for UI 2.

- Line 6, Morning Time Set: Select by using the LEFT or RIGHT buttons. (Press MENU to close
- Line 7, Afternoon Time Set: Select by using the LEFT or RIGHT buttons. (Press MENU to close)
- Line 8, Evening Time Set: Select by using the LEFT or RIGHT buttons. (Press MENU to close)
- Line 9, Night Time Set: Select by using the LEFT or RIGHT buttons. (Press MENU to close)

UI 1 displays the day, time, date, month and year with no abbreviation UI 2 displays "Now it's " Press button OK to switch between UI 1 and UI 2.





