CARE INSTRUCTIONS FOR Q2099 QUALITY PRINT BASE CLOTH

- REMOVE SPILLAGES PROMPTLY WITH AN ABSORBENT DRY CLOTH. VACUUM AND WIPE CLEAN REGULARLY WITH A DAMP CLOTH TO REMOVE DUST PARTICLES AND PREVENT BUILD UP OF SOILING
- FOR HEAVIER SOILING USE A MILD LIQUID SOAP AND WATER, ENSURING THAT CLEANING PRODUCT RESIDUES ARE FULLY RINSED OUT AS THEY CAN INHIBIT THE STAIN REPELLENT IN THE FABRIC
- VACUUM AND WIPE CLEAN REGULARLY WITH A DAMP CLOTH TO REMOVE DUST PARTICLES AND PREVENT BUILD UP OF SOILING.
- REMOVE BODILY FLUIDS PROMPTLY (WITHIN 15 MINUTES) WITH COLD WATER AND CLEAN AS POINTS 22 AND 23 DESCRIBE
- CLEAN AND CARE FOR YOUR UPHOLSTERY ON A REGULAR BASIS AND IT WILL MAINTAIN ITS CONDITION AND APPEARANCE
- DO NOT MACHINE WASH, FULLY IMMERSE, DRY CLEAN OR APPLY OTHER CHEMICAL/STAIN REMOVERS
- IF NECESSARY USE A MILD DISINFECTANT OR BLEACH DILUTED TO 3 PARTS PER 100
- FOR OIL BASED STAINS, USE A DILUTED DETERGENT SOLUTION. RINSE WELL WITH CLEAN, COLD WATER AND ENSURE THAT NO DETERGENT IS LEFT ON THE FACE OF THE FABRIC.