

Repose is an effective aid in the prevention of pressure ulceration for all patients including those assessed as very high risk, and for the treatment of existing pressure ulcers. Clinical supervision is advised if damage is severe.

To Inflate

- 1 Remove Sole Protector from the tube, refit the two tubes together to form a pump.
- 2 Connect the valve on the pump to the valve on the Sole Protector - Push to fit.
- 3 Inflate until you hear air exhausting from the pump valve. Discontinue pumping and wait until you no longer hear air escaping.
- 4 Cover the valve using the solid end of the valve cap.
- 5 Ensure valve is on the outside of the Sole Protector.

Fitting Instructions

- A Place product in position at the foot end of the bed.
- **B** Place vertical straps as shown in figure B then fasten as figure A.
- C Place horizontal straps as shown in figure C then fasten as figure A.
- D To remove product straps refer to figure D.


To Deflate


- 6 Insert the open end of the valve cap into the valve. Air can now escape from the valve allowing the Sole Protector to deflate.
- 7 Roll up the device starting at the point furthest away from the valve. Continue until all air is expelled.
- 8 Clean, and allow to dry. Replace Sole Protector into the pump. Refit the two tubes together and rotate outer tube until it clicks closed.













Check device daily to ensure proper inflation level. In case of doubt, repeat inflation procedure with the user off the product. Keep away from babies, small children and pets. Avoid contact with heat and sharp objects. If deterioration in skin condition is noted, seek clinical advice. Latex Free.

REPOSEDIRECT.COM

